

# **Wonderful Communication, Mobile Life.**

Thank you for purchasing Wireless Terminal.

Wireless Terminal  
User Manual

**Copyright © 2008 Huawei Technologies Co., Ltd.**

**All Rights Reserved**

No part of this manual may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Technologies Co., Ltd.

**Trademarks**



HUAWEI and HUAWEI are trademarks of Huawei Technologies Co., Ltd. All other trademarks mentioned in this manual are the property of their respective holders.

**Notice**

The information in this manual is subject to change without notice. Every effort has been made in the preparation of this manual to ensure accuracy of the contents, but all statements, information, and recommendations in this manual do not constitute the warranty of any kind, expressed or implied.

# Contents

<b>1</b>	<b>Management Program Installation.....</b>	<b>1</b>
<b>2</b>	<b>Parameter Settings .....</b>	<b>2</b>
	<b>Launching the Management Program.....</b>	<b>2</b>
	<b>Setting Profile Parameters.....</b>	<b>2</b>
	<b>Managing the PIN .....</b>	<b>3</b>
	<b>Setting the Searching Function .....</b>	<b>3</b>

# 1

## Management Program Installation

For the data card that cannot support the PNP function, the installation operation of management program as follows:

1. Place the installation CD-ROM into your DVD driver and select the installation package.  

2. Double-click the installation package.
3. Install the management program according to the prompts.

Note:

For the data card that cannot support the PNP function, connect the data card to your PC after the management program in the CD-ROM is installed completely.

For the data card that can support the PNP function, the installation operation of management program as follows:

1. Plug-in the data card into your computer.
2. System automatically displays the installation file and you can double-click it.
3. Install the management program according to the prompts.

Note:

- you are required to enter the account and password of the system administer before completing the installation.
- The management program requires the operating system (OS) should be Mac OS X 10.4 and 10.5 with latest upgrades.

# 2 Parameter Settings

When the management program is installed successfully, you can launch the program and set the parameters. The following sections describe the detailed procedure.

## Launching the Management Program

---

1. Insert the SIM card into the data card.
2. Connect the data card to your PC.
3. Open the **Finder** window, and select the terminal management in the **Application** directory. Then launch the management program of the terminal management. If the Personal Identification Number (PIN) code of the data card is locked, the system displays the **Verify PIN** dialog box for you to enter the PIN code.
4. If you enter wrong PINs for three consecutive times, the system displays the **PIN Unblocking Key** dialog box for you to enter the valid PIN Unblocking Key (PUK).

Note:

- If you enter wrong PUKs for ten consecutive times, the SIM card is invalid permanently.
- The PIN and PUK are delivered with the SIM card provided by your service provider. For details, consult your service provider.

## Setting Profile Parameters

---

Select **Profile Name** and click **Connect** for the dial-up access.

The operation about adding profile name as follows:

1. In the main interface of the management program, click **Setting**. Then the interface for setting parameters is displayed.

2. Click **New** to set the profile parameters.

Note:

- You can select a profile name in the Profile Name drop-down list. When there is no desired profile name in the list, you need to create one.
- The profile name is decided by your own.
- The values for Access Point Name, Telephone Number, Account Name and Password are obtained from the service provider.
- By default, the value of Telephone Number is set to \*99#.

3. Click **Save** to save the settings.

4. Click **OK** to return to the terminal management interface.

Note:

During the dial-up access, the Mac OS X system requires you to enter the account and password of the system administer. You can access the Internet only when the correct account and password are entered.

## Managing the PIN

---

1. On the menu bar of the management program main interface, choose **Manage PIN > Active** to activate the PIN protection.  
Choose **Manage PIN > Deactive** to deactivate the PIN protection.
2. Choose **Manage PIN > Modify** to modify the PIN code.

Note:

- You should enter the correct digits in the Current PIN code text box.
- The values entered in the New PIN Code and the Confirm text box should keep consistent.

## Setting the Searching Function

---

1. On the menu bar of the management program main interface, choose **Select Network > Manual**.

2. In the **Profile Name** list, select a profile name to be registered.
3. Click **Register** to registered the network.

Note:

By default, the management program uses the function of searching the network automatically.